Bicycle GPS Computer Manual



INTRODUCTION

1.Initial Setups

Long press the left [power]button for 2 seconds to turn on the device. When you use this device for the first time, press Right [set] button for 2 seconds to enter the setting mode and set the temperature ,the time zone and the units.

a.select temperature ℃ or ℉ and the time zone:
Choose the correct time zone based on your location.

b.select the units:
You can choose units in kilometers per hour(KM/H) or miles per hour(M/H).

You can also sync your phone' s time to the bike computer after it connects to the APP.

Note: After synchronizing the time via the APP, the bike computer time will match your phone' s time instead of using the time zone set on the bike computer.

3.Button Functions

This device has two function buttons, which are easy to operate.Check the table below to see what each key does in different situation.


Button	Function
① POWER ▶‖ ⏻	Long press for 2 seconds to power ON/OFF Short press to Start/Pause riding
② ↻ ⊟	Long press for 2 seconds to enter setting mode Short press to turn page
①+②	Hold ① and ② key for 2 seconds to Save data to the bike computer Hold ① and ② key for 6 seconds to clear Total mileage

4. Status Icons

8888	Time	RTM	Sport time
	No satellite signal	ALT	Altitude
	Satellite signal level	TTM	Total riding time
▶	Start recording	ODO	Odometer (Total distance)
‖	Manual pause	DST	Trip Distance
	Temperature	AST	Ascend Distance
AVG	Average Speed	GRA	Gradient
MXS	Maximum	UTC	Time zone
mi	Miles per hour		Battery level
inh	Kilometers per hour		
▲▼	Below average speed & above average speed		

5.STANDARD PACKAGE

Packing List A



Bike Computer*1 · Rubber Ring*2 · Manual*1 · Mount*1 · Rubber Pad*1 · Charging Cable*1

6.How to Install

Install the device base:

Secure it to the handlebar with the included rubber ring.

1 Install the rubber pad on the back of the device base.

2 Choose a suitable position on the handlebar to place the rubber pad and the base of the device.

3 Use rubber rings to go around the handle respectively, hook the buckle of the base of the computer,and fix it on the handlebar.

4 Align the protruding position of the buckle on the back of the computer with the slot on the base of the device, and rotate it 90 degrees.

Note: This device is compatible with the base and extension bracket of most GPS computer.



Use bike computer mount.
Use rubber bands to cross and fix the base

7.Phone Pairing (Data Download)

Please download the BKEVEE app from the App Store or Google Play, and connect your device to your mobile phone.

Google Play · App Store

After installing the APP, please log in as required.
Open the APP, tap Device, then Add Bike Computer.
Select the corresponding model and tap it to finish pairing.
Return to the home page and tap Synchronous Data to upload riding data to the APP.Tap Connected to enter the bike computer settings page, where you can adjust backlight duration, speed unit, time zone, language, and sync phone time to the bike computer.

8.Time Zone Setting /12H/24HFormat setting

1.1 Hold the ⚙ to get into setting mode;
1.2 Press ↔ to set the numbers;
1.3 Press ⚙ to next setting




Time Zone:UTC +8:00



12H/24HFormat setting

9.Setting Metric and imperial Units

1.1 Hold the ⚙ to get into setting mode;
1.2 Press ↔ to seclet metric system (KMH) or imperial system (MPH) (default is metric system).
1.3 Press ⚙ to save and exit.



Set the metric units · Press the Left button · Set the imperial units

10.Cycling

Data display mode 1

1.1 Turn on the device, Press ⚙ to start recording .
(The device will automatically go into sleep mode six minutes after you stop cycling. When you start cycling again, the device will automatically wake up and turn on the backlight.)

1.2 Press ⚙ to view the riding data .
1.3 This device has three display modes, press ⚙ button to display next page

1.4 The mode 1 displays: Riding Time, Riding Distance, Gradient, Altitude Ascend Distance , ODO



Data display mode 2

1.1 Press ⚙ to view the riding data.
1.2 Press ⚙ button to display next page .
1.3 The mode 2 displays: Average Speed, Ascend Distance, Average Gradient, total riding time,Riding Distance, Altitude



Data display mode 3

1.1 Press ⚙ to view the riding data
1.2 Press ⚙ button to display next page .
1.3The mode 3 displays: Maximum Speed, ODO, Maximum Gradient, Maximum Altitude Riding Distance,Ascend Distance,



Save Data

In the cycling mode, if you press the left and right keys simultaneously for two seconds, you can save data the current cycling data. The bike computer can store up to 10 data records.When the number exceeds 10, the first record will be overwritten.Please upload data to the app in time. After uploading, only total distance and total time will be shown on the bike computer.

Clear Data

If you press them for six seconds,
all data will be cleared, including the total mileage.

11.GPS Positioning Anomaly

1.GPS searching is Auto After power on. Please start cycling after the GPS positioning is successful.
2.If you start riding when the GPS is not positioned successfully the speed data will be displayed as" 0.0" , and the rest of the data remains the same.
Tips: You can stand still 1-2 minutes to get more connections with satellites for better GPS signal.
Note: Please make sure you are outdoor when positioning. Bad weather and dense forest may affect GPS signal.

12.Acquiring Satellite Signals,Auto Back Light

Automatic sleep /wake-up function

After stopping riding for 6 minutes ,it enters into sleep mode, When riding again, the device will automatically wake up and turn on.
Press both buttons at the same time to turn on the backlight, which will remain on while riding. You can set the backlight duration and the on/off time of the backlight in the APP.

Acquiring Satellite Signals

Please make sure the device is outdoor and under a clear view of sky. Usually it may take About 30-120 seconds
seconds to locate satellite signals, remain stationary when acquiring satellite signals.

13.Charging

1. Please charge the device before first time use;
2. Please use DC 5V power adaptor for charging;
3. During the charging, the battery icon will flash until fully charged.
4. It will automatically power off while charging.

Note: Please use a DC 5V adaptor to charge. It is not recommended to use a fast-charging adapter to charge the bike computer, as it may cause damage to the product' s battery.



14.Basic Parameters

Locate Mode: GPS & BDS & GLONASS & GALILEO & QZSS
Display: FSTN Screen,2.6 inch
Back Light: Yes
Water Resistance:IPX7
Weight: 57g
Storage Format: fit
File Transfer: Buletooth (Specified App Compatible)
Language: English
Battery Life: 28 hours
Material: PC+ABS
Dimension: 80mm×50mm×16mm

Attentions

The water resistant level of the bicycle computer is IPX7. it can be used in the rain if you close the protective cover on the back tightly. it is recommended to take down the bicycle computer and put it into waterproof bag if it rains heavily.

Responsibility Disclaimer

The information contained in this manual are just for reference The product described above may be subject to alteration owing to the manufacturer's continuing research and development plans, without making an announcement in advance.

We shall not bare any legal responsibility for any direct or indirect, accidental or special damages, losses and expenses arising from or in connection with this manual or the contained product.